

ROOFLINE

by **timloc**

FELT SUPPORT TRAY

INSTALLATION ADVICE

Designed to prevent damage to roofing felt



Satisfies all NHBC requirements



Manufactured to BS EN ISO 9001 and BS EN ISO 14001



Complies with all relevant Building Regulations



Meets all relevant British Standards

1.

Fit on the top of the fascia board below roofing felt, allowing a 150mm overlap where pieces join.

2.

Secure with clout nails and fold back the rear flap to rest on the rafters.

Scan or click to view the product datasheet

