

PLASTIC ACCESS PANELS INSTALLATION ADVICE

The answer to unsightly controls and fittings



Manufactured to BS EN ISO 9001
and BS EN ISO 14001



Helps to meet Building Regulation
document Part J (2010 edition)

1.

Cut hole to size, making sure that it is straight and level.

2.

Apply silicon or other suitable grade building adhesive to the back of the frame.

3.

Check which way that you want the door to hinge. Press the frame firmly into place, checking it is straight and level.

4.

Do not operate until the adhesive has set completely. To open the door, use a screw driver in the slot and lever up (Fig. 1).

5.

To remove the door, open the door slightly (Fig 2.) and pull away from the hinge position maintaining the door at a slight angle (Fig. 3). This does not apply to panels AP110 and AP200 which are clip fit door panels. To replace the door, reverse the removal process.

Scan or click to view the
product datasheet

