

**ROOFLINE**

by **timloc**

RAFTER ROLL

# INSTALLATION ADVICE

**Roll out system to maintain ventilation  
between insulation and roofing felt**



-  Satisfies all NHBC requirements
-  Manufactured to BS EN ISO 9001 and BS IN ISO 14001
-  Complies with all relevant Building Regulations
-  Meets all relevant British Standards

**1.**

Unroll the ventilator along the rafters along the full length of the eaves and along both sides of the building to create a cross flow ventilation action.

**2.**

Position centrally above the wall plate. This is the narrowest part of the roof where the roof insulation is most likely to constrict the airflow.

**3.**

Push the corrugations down over the top of the rafters and secure using clout nails or staples.

Scan or click to view the  
product datasheet

