



INSTALLATION GUIDE

Universal dry fix verge system for profiled roof tiles



Helping to meet BS 5534 Code of practice for slating and tiling


Manufactured to BS EN ISO 9001 and BS EN ISO 14001

Complies with all relevant Building Regulations

Independently tested and complies with BS8612

Mechanically fixed dry verge system for profiled tiles that provides a robust, attractive, and weather-protective alternative to wet mortar bedding.


Please read these instructions carefully before starting work. We recommend that installation and preparations are carried out by a competent tradesperson.



1.


Prepare the tile batten ends along the verge. Timloc recommends using counter battens to avoid fixing directly into the tile batten end grain.

- a. If fixing directly to the tile batten ends allow a 50mm overhang.
- b. If fitting counter battens under the tile battens allow a 50mm overhang.
- c. If fitting counter battens onto the ends of the tile battens allow a 25mm overhang to the tile battens to give a 50mm total overhang.



7.

To complete the installation fit a ridge cap over the ridge tile and left and right verge units. Fix the cap in place with screws through the centre recesses and into the ridge board. The outer edges of the ridge cap can be flexed or trimmed to length to allow a closer fit to the top course of the verge units if required.



8.

Once the installation is complete check that all verge units, starters and ridge caps are fitted securely.

Scan or click to view product datasheet

