

by **timloc**


Fixing Instructions | 3m | 6m | 10m Integrated Dry Ridge Kit

A robust, attractive and weather-resistant verge system alternative to wet mortar bedding.




Apply the roofing underlay as normal practice leaving a gap of approximately 30mm short of the apex at both sides to allow for ventilation.

a. Fix the battens as required, omitting the top course at this stage to allow for the ridge batten bracket fixing.



Span lengths of ridge batten along the roof apex and nail in place.

 ${\bf a.}\ Level the ridge batten and final secure fix with the metal batten straps provided. \\ {\bf Fix}\ and fold\ strap\ over ridge\ batten\ and\ secure\ to\ rafters\ at\ both\ sides\ of\ ridge. \\$



Place the ridge tiles along the ridge and join using the ridge union provided.


a. The ridge tile should be positioned underneath the integrated clips.



Use:

- · Most types of slate, concrete or clay roof tiles
- Round or angled ridge tiles
- Most pitched roof types from 15-55°
- New build and retro-fit projects


For additional product information please refet to the Integrated Dry Ridge Kit datasheet.



Lay out the roll evenly along the centre of the ridge batten and tack into position as the work proceeds using suitable roofing grade nails at rafter centre intervals. A minimum overlap of 100mm is required when starting a fresh roll along the ridge length.

a. The butyl securing tape to the underside of the corrigated edge should be applied as work proceeds by removing the release paper and pressing the tape into the tile profile. Check the surface is free of debris and water prior to application.

 $\boldsymbol{b.}$ Ensure that a full seal along the ridge length at both sides is achieved.



Position the adjacent ridge tile and then securely fix the screw and metal clamping plate through the top hole in the ridge union and into the ridge batten.

- a. Repeat the process along all of the ridge tiles.
- **b.** At the end of the ridge the final tile should be fixed using one of the following methods:
- 1. Drilled hole through the ridge tile with a screw down into the ridge batten.
- 2. Mortar applied underneath the end of the ridge tile.
- 3. A dry ridge end cap overlapping the ridge tile.

