


FREE
call off &
scheduling
service

CAVITY TRAYS

Leaded and unleaded cavity trays for
brickwork, blockwork, stonework and more

timloc
building products

CAVITY TRAYS



At Timloc, we offer a wide range of preformed leaded and unleaded cavity trays to meet almost any application requirement and type of masonry. We also have a wealth of experience in designing and manufacturing non-standard cavity trays for project requirements. Our cavity tray service comes with free product specification, project scheduling and plot specific delivery consignments as needed.

WHY TRUST TIMLOC WITH THE FULL PACKAGE?



Quality, reliable and durable products



Free cavity tray specification and scheduling



Leaded and unleaded options available*



Expert Technical support



Full data sheets available at timloc.co.uk



Unrivalled next working day delivery service*

*on select products

CONTENTS

Stepped

Everdry Stepped - Brickwork	6
Everdry Stepped - Stonework	8
Everdry Stepped - Blockwork	10
Everdry Stepped - Brickwork - Lead Attached	12
Everdry Stepped - Stonework - Lead Attached	14
Everdry Stepped - Blockwork - Lead Attached	16

Horizontal

Inter-loc Horizontal	18
Inter-loc Horizontal - Lead Attached	20
System 2000 Horizontal	22
System 2000E Horizontal - Refurbishment	24
System 2000 Horizontal - Lead Attached	26

Other

General Purpose Trays	28
Horizontal Parapet Trays	29
Lintel Trays	30
Threshold Trays	31
Door & Window Trays	32
Purpose Made Trays	33

TECHNICAL SUPPORT

Full product information is available on the Timloc website. If you require any further assistance please contact Technical via the details below:

Phone: **01405 782 769** | Email: **technical@timloc.co.uk**

Scan the QR code to view full product datasheets.



Use the table below to establish which Timloc cavity tray is best suited to your project specification. If you require any further assistance please contact Technical via the details below: Phone: **01405 782 769** | Email: **technical@timloc.co.uk**

CAVITY TRAY → APPLICATION ↓	EVERDRY	INTER-LOC	SYSTEM 2000	SYSTEM 2000E	OVER LINTEL	GENERAL PURPOSE	PARAPET HORIZONTAL	PURPOSE MADE	DOOR & WINDOW	LINTEL STOPEND
PITCHED ROOF	✓									
FLAT ROOF		✓	✓	✓						
LEAN-TO		✓	✓	✓						
MONO-PITCH		✓	✓	✓						
CONCRETE RING BEAMS		✓	✓			✓				
AIRBRICKS, DUCTS, LINERS, METER BOXES ETC.		✓	✓	✓		✓				
EXISTING WALLS (REMEDIAL WORK)		✓		✓						
STEEL LINTELS					✓					✓
PARAPET WALLS							✓			
DPC APPLICATIONS								✓		
DOOR & WINDOW ARCHES									✓	
CIRCULAR WINDOWS									✓	
LEADED OPTIONS	✓	✓	✓							

FREE
NEXT DAY
DELIVERY

*All orders placed before 12pm Monday - Friday will be delivered the next working day. Applicable to standard stock items only, please see individual product pages for more information.

on orders over
£100 to branch
or **£150** to
site



Timloc Building Products offers a wide range of preformed cavity trays to meet almost any application requirement and type of masonry. Here is a brief overview of the cavity trays available:

EVERDRY STEPPED



Stepped cavity tray system with variable bed thickness options for brick, block and stone work. Available leaded and unleaded.

INTER-LOC HORIZONTAL



Pre-formed horizontal cavity tray system for new build and existing walls. Leaded and unleaded options available.

SYSTEM 2000 HORIZONTAL



Horizontal cavity tray system suitable for new build brick/block/stone work constructions.

SYSTEM 2000E HORIZONTAL




Horizontal cavity trays suitable for remedial work on existing brick, block or stone work.

LINTEL TRAYS



For installation directly above modern steel lintels in external cavity walls.

THRESHOLD TRAYS



Preformed DPC threshold protection trays to suit standard openings.

GENERAL PURPOSE



For installation in various applications such as above floor beams, roof abutments and meter boxes

HORIZONTAL PARAPET



For installation directly into the internal wall of parapet wall applications.

PURPOSE MADE



Special made-to-measure damp proof course units for DPC applications.

DOOR & WINDOW



Made-to-measure for all types of door and window arches and circular windows.

PLOT-SPECIFIC DELIVERY

Plot delivery is available for leaded, unleaded and polystrip cavity trays. There will be a 25% surcharge for unleaded and polystrip tray plot deliveries.

Please specify on your order if you require this service.

EVERDRY STEPPED CAVITY TRAYS **BRICKWORK**



USE

- At the abutment of a pitched roof with a cavity wall
- On external walls - not exceeding 120mm thickness - built from standard brickwork or similar sized components with regular course heights, including mortar of approx. 75mm
- On roof pitches of 10° and above



PRODUCTS IN THE RANGE

Intermediate trays: Forms main tray run with one tray on each course of brickwork running the full length of the abutting roof slope.

Stopend starters: Suits all roof pitches - first component to be installed and fitted at the lowest point on a standard abutment. Collects water gathered by the rest of the system and discharges it from the wall through a weep hole.

Corner starter trays: Suits all roof pitches - has same function as stopend starter tray but is used where the abutting roof comes up to, or beyond, the corner of the main building. Designed to return around the corner of the building to provide complete protection.


Ridge trays: Suits all roof pitches - used where a right hand and left hand roof slope come together at an apex to straddle the top two intermediate trays.




Intermediate tray
(LH)



Stopend starter tray
(LH/RH)



Corner starter tray
(LH/RH)



Ridge tray

STEPPED CAVITY TRAYS SLOPING MEASUREMENT ROOF PITCH	COURSING HEIGHT 75MM BRICK	STEPPED CAVITY TRAYS HORIZONTAL MEASUREMENT ROOF PITCH	COURSING HEIGHT 75MM BRICK
10°	2.3	10°	2.4
12.5°	2.9	12.5°	3.0
15°	3.5	15°	3.6
17.5°	4.0	17.5°	4.2
20°	4.6	20°	4.9
22.5°	5.1	22.5°	5.5
25°	5.6	25°	6.2
27.5°	6.2	27.5°	7.0
30°	6.7	30°	7.7
32.5°	7.2	32.5°	8.5
35°	7.7	35°	9.3
37.5°	8.1	37.5°	10.2
40°	8.6	40°	11.2
42.5°	9.0	42.5°	12.2
45°	9.4	45°	13.3

DESCRIPTION	LENGTH	HANDING	75MM BRICK COURSING PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF 50-110MM	LEAD TIME
Intermediate tray	225mm	RH	10001	Next Working Day
Intermediate tray	225mm	LH	10002	Next Working Day
Intermediate tray	420mm*	RH	10011	Next Working Day
Intermediate tray	420mm*	LH	10012	Next Working Day
Stopend starter tray	225mm	RH/LH	10031	Next Working Day
Corner starter tray	225mm	RH/LH	10041	Next Working Day
Ridge tray	225mm	N/A	10061	Next Working Day
Ridge tray	420mm	N/A	10062	Next Working Day

For trays featuring the polystyrene strip mortar barrier insert 'P' at the end of the required product code. This may incur an additional charge.

N.B * For roof pitches 15°- 22.5°. Stopend starter, corner starter and ridge trays suit all roof pitches. 525mm long tray available "fixed cavity" for roof pitches 10°-15°

EVERDRY STEPPED CAVITY TRAYS **STONEMWORK**



USE

- At the abutment of a pitched roof with a cavity wall
- On external walls - not exceeding 150mm thickness - built from natural or reconstituted stone with regular course heights, including mortar of approx. 150mm
- On roof pitches of 7.5° and above
- Contact Timloc Technical for larger cavity widths



PRODUCTS IN THE RANGE

Intermediate trays: Forms main tray run with one tray on each course of stonework running the full length of the abutting roof slope.

Stopend starters: Suits all roof pitches - first component to be installed and fitted at the lowest point on a standard abutment. Collects water gathered by the rest of the system and discharges it from the wall through a weep hole.

Corner starter trays: Suits all roof pitches - has same function as stopend starter tray but is used where the abutting roof comes up to, or beyond, the corner of the main building. Designed to return around the corner of the building to provide complete protection.

Ridge trays: Suits all roof pitches. Used where a right hand and left hand roof slope come together at an apex to straddle the top two intermediate trays.




Intermediate tray
(LH)



Stopend starter tray
(LH/RH)



Corner starter tray
(RH)



Ridge tray

150MM STONE COURSING - 100MM EXTERNAL WALL THICKNESS (BED)

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	450mm	7101	Next Working Day	7103	3-5 Working Days	7105	3-5 Working Days
Intermediate tray LH	450mm	7102	Next Working Day	7104	3-5 Working Days	7106	3-5 Working Days
Intermediate tray RH	625mm	7111	3-5 Working Days	7113	3-5 Working Days	7115	3-5 Working Days
Intermediate tray LH	625mm	7112	3-5 Working Days	7114	3-5 Working Days	7116	3-5 Working Days
Intermediate tray RH	1250mm	7121	3-5 Working Days	7123	3-5 Working Days	7125	3-5 Working Days
Intermediate tray LH	1250mm	7122	3-5 Working Days	7124	3-5 Working Days	7126	3-5 Working Days
Stopend starter RH/LH	450mm	7131	Next Working Day	7133	3-5 Working Days	7135	3-5 Working Days
Corner starter tray RH	550mm	7141	Next Working Day	7143	3-5 Working Days	7145	3-5 Working Days
Corner starter tray LH	550mm	7142	Next Working Day	7144	3-5 Working Days	7146	3-5 Working Days
Ridge tray	450mm	7161	Next Working Day	7162	3-5 Working Days	7163	3-5 Working Days

150MM STONE COURSING - 125MM EXTERNAL WALL THICKNESS (BED)


DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	450mm	7103	3-5 Working Days	7105	3-5 Working Days	7107	3-5 Working Days
Intermediate tray LH	450mm	7104	3-5 Working Days	7106	3-5 Working Days	7108	3-5 Working Days
Intermediate tray RH	625mm	7113	3-5 Working Days	7115	3-5 Working Days	7117	3-5 Working Days
Intermediate tray LH	625mm	7114	3-5 Working Days	7116	3-5 Working Days	7118	3-5 Working Days
Intermediate tray RH	1250mm	7123	3-5 Working Days	7125	3-5 Working Days	7127	3-5 Working Days
Intermediate tray LH	1250mm	7124	3-5 Working Days	7126	3-5 Working Days	7128	3-5 Working Days
Stopend starter RH/LH	450mm	7133	3-5 Working Days	7135	3-5 Working Days	7137	3-5 Working Days
Corner starter tray RH	550mm	7143	3-5 Working Days	7145	3-5 Working Days	7147	3-5 Working Days
Corner starter tray LH	550mm	7144	3-5 Working Days	7146	3-5 Working Days	7148	3-5 Working Days
Ridge tray	450mm	7162	Next Working Day	7163	3-5 Working Days	7164	3-5 Working Days

150MM STONE COURSING - 150MM EXTERNAL WALL THICKNESS (BED)

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	450mm	7105	3-5 Working Days	7107	3-5 Working Days	7109	3-5 Working Days
Intermediate tray LH	450mm	7106	3-5 Working Days	7108	3-5 Working Days	7110	3-5 Working Days
Intermediate tray RH	625mm	7115	3-5 Working Days	7117	3-5 Working Days	7119	3-5 Working Days
Intermediate tray LH	625mm	7116	3-5 Working Days	7118	3-5 Working Days	7120	3-5 Working Days
Intermediate tray RH	1250mm	7125	3-5 Working Days	7127	3-5 Working Days	7129	3-5 Working Days
Intermediate tray LH	1250mm	7126	3-5 Working Days	7128	3-5 Working Days	7130	3-5 Working Days
Stopend starter RH/LH	450mm	7135	3-5 Working Days	7137	3-5 Working Days	7139	3-5 Working Days
Corner starter tray RH	550mm	7145	3-5 Working Days	7147	3-5 Working Days	7149	3-5 Working Days
Corner starter tray LH	550mm	7146	3-5 Working Days	7148	3-5 Working Days	7150	3-5 Working Days
Ridge tray	450mm	7163	Next Working Day	7164	3-5 Working Days	7165	3-5 Working Days

For trays featuring the polystyrene strip mortar barrier insert 'P' at the end of the required product code. This may incur an additional charge.

EVERDRY STEPPED CAVITY TRAYS **BLOCKWORK**



USE

- At the abutment of a pitched roof with a cavity wall
- On external walls - not exceeding 150mm thickness - built from blockwork or stone with regular course heights, including mortar of approx. 225mm
- On roof pitches of 12.5° and above
- Contact Timloc Technical for larger cavity widths




PRODUCTS IN THE RANGE

Intermediate trays: Forms main tray run with one tray on each course of blockwork/stonework running the full length of the abutting roof slope.


Stopend starters: Suits all roof pitches - first component to be installed and fitted at the lowest point on a standard abutment. Collects water gathered by the rest of the system and discharges it from the wall through a weep hole.

Corner starter trays: Suits all roof pitches - has same function as stopend starter tray but is used where the abutting roof comes up to, or beyond, the corner of the main building. Designed to return around the corner of the building to provide complete protection.


Ridge trays: Suits all roof pitches - used where a right hand and left hand roof slope come together at an apex to straddle the top two intermediate trays.




Intermediate tray
(LH)



Stopend starter tray
(LH/RH)



Corner starter tray
(RH)



Ridge tray

225MM BLOCK COURSING - 100MM EXTERNAL WALL THICKNESS (BED)

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	625mm	7201	Next Working Day	7203	3-5 Working Days	7205	3-5 Working Days
Intermediate tray LH	625mm	7202	Next Working Day	7204	3-5 Working Days	7206	3-5 Working Days
Intermediate tray RH	1250mm	7211	3-5 Working Days	7213	3-5 Working Days	7215	3-5 Working Days
Intermediate tray LH	1250mm	7212	3-5 Working Days	7214	3-5 Working Days	7216	3-5 Working Days
Stopend starter RH/LH	450mm	7231	Next Working Day	7233	3-5 Working Days	7235	3-5 Working Days
Corner starter tray RH	550mm	7241	3-5 Working Days	7243	3-5 Working Days	7245	3-5 Working Days
Corner starter tray LH	550mm	7242	3-5 Working Days	7244	3-5 Working Days	7246	3-5 Working Days
Ridge tray	625mm	7261	Next Working Day	7262	3-5 Working Days	7263	3-5 Working Days

225MM BLOCK COURSING - 125MM EXTERNAL WALL THICKNESS (BED)


DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	625mm	7203	3-5 Working Days	7205	3-5 Working Days	7207	3-5 Working Days
Intermediate tray LH	625mm	7204	3-5 Working Days	7206	3-5 Working Days	7208	3-5 Working Days
Intermediate tray RH	1250mm	7213	3-5 Working Days	7215	3-5 Working Days	7217	3-5 Working Days
Intermediate tray LH	1250mm	7214	3-5 Working Days	7216	3-5 Working Days	7218	3-5 Working Days
Stopend starter RH/LH	450mm	7233	3-5 Working Days	7235	3-5 Working Days	7237	3-5 Working Days
Corner starter tray RH	550mm	7243	3-5 Working Days	7245	3-5 Working Days	7247	3-5 Working Days
Corner starter tray LH	550mm	7244	3-5 Working Days	7246	3-5 Working Days	7248	3-5 Working Days
Ridge tray	625mm	7262	3-5 Working Days	7263	3-5 Working Days	7264	3-5 Working Days

225MM BLOCK COURSING - 150MM EXTERNAL WALL THICKNESS (BED)

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	625mm	7205	3-5 Working Days	7207	3-5 Working Days	7209	3-5 Working Days
Intermediate tray LH	625mm	7206	3-5 Working Days	7208	3-5 Working Days	7210	3-5 Working Days
Intermediate tray RH	1250mm	7215	3-5 Working Days	7217	3-5 Working Days	7219	3-5 Working Days
Intermediate tray LH	1250mm	7216	3-5 Working Days	7218	3-5 Working Days	7220	3-5 Working Days
Stopend starter RH/LH	450mm	7235	3-5 Working Days	7237	3-5 Working Days	7239	3-5 Working Days
Corner starter tray RH	550mm	7245	3-5 Working Days	7247	3-5 Working Days	7249	3-5 Working Days
Corner starter tray LH	550mm	7246	3-5 Working Days	7248	3-5 Working Days	7250	3-5 Working Days
Ridge tray	625mm	7263	3-5 Working Days	7264	3-5 Working Days	7265	3-5 Working Days

For trays featuring the polystyrene strip mortar barrier insert 'P' at the end of the required product code. This may incur an additional charge.

EVERDRY STEPPED CAVITY TRAYS **BRICKWORK** LEADED



USE

- At the abutment of a pitched roof with a cavity wall
- On external walls - not exceeding 120mm thickness - built from standard brickwork or similar sized components with regular course heights, including mortar of approx. 75mm
- On roof pitches of 10° and above



PRODUCTS IN THE RANGE

Intermediate trays: Forms main tray run with one tray on each course of brickwork running the full length of the abutting roof slope.

Stopend starters: Suits all roof pitches - first component to be installed and fitted at the lowest point on a standard abutment. Collects water gathered by the rest of the system and discharges it from the wall through a weep hole.

Corner starter trays: Suits all roof pitches - has same function as stopend starter tray but is used where the abutting roof comes up to, or beyond, the corner of the main building. Designed to return around the corner of the building to provide complete protection.

Ridge trays: Suits all roof pitches - used where a right hand and left hand roof slope come together at an apex to straddle the top two intermediate trays.




Intermediate tray (LH) Short Lead



Intermediate tray (LH) Long Lead



Stopend starter tray (LH) Short Lead



Corner starter tray (LH) Long Lead



Ridge tray


STEPPED CAVITY TRAYS SLOPING MEASUREMENT ROOF PITCH	COURSING HEIGHT 75MM BRICK	STEPPED CAVITY TRAYS HORIZONTAL MEASUREMENT ROOF PITCH	COURSING HEIGHT 75MM BRICK
10°	2.3	10°	2.4
12.5°	2.9	12.5°	3.0
15°	3.5	15°	3.6
17.5°	4.0	17.5°	4.2
20°	4.6	20°	4.9
22.5°	5.1	22.5°	5.5
25°	5.6	25°	6.2
27.5°	6.2	27.5°	7.0
30°	6.7	30°	7.7
32.5°	7.2	32.5°	8.5
35°	7.7	35°	9.3
37.5°	8.1	37.5°	10.2
40°	8.6	40°	11.2
42.5°	9.0	42.5°	12.2
45°	9.4	45°	13.3

DESCRIPTION	LENGTH	HANDING	75MM BRICK COURSING PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF 50-110MM	LEAD TIME
Intermediate tray	Varies	RH	20001	3-5 Working Days for 10° - 22.5°. Next Working Day available on 25° and above only.
Intermediate tray	Varies	LH	20002	
Stepend starter tray	225mm	RH/LH	20031/32	
Corner starter tray	225mm	RH/LH	20041/42	
Ridge tray	225mm	N/A	20061	
Ridge tray	420mm	N/A	20062	

When ordering, please state roof pitch and whether long or short leads are required.

N.B Intermediate trays are 225mm in length at roof pitches of 27.5 degrees and above. Below this pitch the length increases to 420mm and 525mm.

EVERDRY STEPPED CAVITY TRAYS **STONEWORK** LEADED



USE

- At the abutment of a pitched roof with a cavity wall
- On external walls - not exceeding 150mm thickness - built from natural or reconstituted stone with regular course heights, including mortar of approx. 150mm
- On roof pitches of 15° and above



PRODUCTS IN THE RANGE

Intermediate trays: Forms main tray run with one tray on each course of stonework running the full length of the abutting roof slope.

Stopend starters: Suits all roof pitches - first component to be installed and fitted at the lowest point on a standard abutment. Collects water gathered by the rest of the system and discharges it from the wall through a weep hole.

Corner starter trays: Suits all roof pitches. Same function as stopend starter tray but is used where the abutting roof comes up to, or beyond, the corner of the main building. Designed to return around the corner of the building for complete protection. Corner starter trays are not supplied with factory fitted lead flashings due to the size and weight of lead flashing required. Flashing in this area should be dealt with separately in the traditional way.

Ridge trays: Suits all roof pitches. Used where a right hand and left hand roof slope come together at an apex to straddle the top two intermediate trays.



Intermediate tray (LH)
Long Lead



Stopend starter tray (LH)
Long Lead



Ridge tray

150MM STONE COURSING - 100MM EXTERNAL WALL THICKNESS (BED)

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	Varies	8101	3-5 Working Days	8103	3-5 Working Days	8105	3-5 Working Days
Intermediate tray LH	Varies	8102	3-5 Working Days	8104	3-5 Working Days	8106	3-5 Working Days
Stopend starter RH	450mm	8131	3-5 Working Days	8133	3-5 Working Days	8135	3-5 Working Days
Stopend starter LH	450mm	8132	3-5 Working Days	8134	3-5 Working Days	8136	3-5 Working Days
Corner starter tray RH*	550mm	7141	Next Working Day	7143	3-5 Working Days	7145	3-5 Working Days
Corner starter tray LH*	550mm	7142	Next Working Day	7144	3-5 Working Days	7146	3-5 Working Days
Ridge tray	450mm	8161	3-5 Working Days	8162	3-5 Working Days	8163	3-5 Working Days

150MM STONE COURSING - 125MM EXTERNAL WALL THICKNESS (BED)

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	Varies	8103	3-5 Working Days	8105	3-5 Working Days	8107	3-5 Working Days
Intermediate tray LH	Varies	8104	3-5 Working Days	8106	3-5 Working Days	8108	3-5 Working Days
Stopend starter RH	450mm	8133	3-5 Working Days	8135	3-5 Working Days	8137	3-5 Working Days
Stopend starter LH	450mm	8134	3-5 Working Days	8136	3-5 Working Days	8138	3-5 Working Days
Corner starter tray RH*	550mm	7143	3-5 Working Days	7145	3-5 Working Days	7147	3-5 Working Days
Corner starter tray LH*	550mm	7144	3-5 Working Days	7146	3-5 Working Days	7148	3-5 Working Days
Ridge tray	450mm	8162	3-5 Working Days	8163	3-5 Working Days	8164	3-5 Working Days


150MM STONE COURSING - 150MM EXTERNAL WALL THICKNESS (BED)

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	Varies	8105	3-5 Working Days	8107	3-5 Working Days	8109	3-5 Working Days
Intermediate tray LH	Varies	8106	3-5 Working Days	8108	3-5 Working Days	8110	3-5 Working Days
Stopend starter RH	450mm	8135	3-5 Working Days	8137	3-5 Working Days	8139	3-5 Working Days
Stopend starter LH	450mm	8136	3-5 Working Days	8138	3-5 Working Days	8140	3-5 Working Days
Corner starter tray RH*	550mm	7145	3-5 Working Days	7147	3-5 Working Days	7149	3-5 Working Days
Corner starter tray LH*	550mm	7146	3-5 Working Days	7148	3-5 Working Days	7150	3-5 Working Days
Ridge tray	450mm	8163	3-5 Working Days	8164	3-5 Working Days	8165	3-5 Working Days

When ordering, please state roof pitch and whether long or short leads are required.

N.B *Not supplied with factory fitted lead flashings.

EVERDRY STEPPED CAVITY TRAYS **BLOCKWORK** LEADED



USE

- At the abutment of a pitched roof with a cavity wall
- On external walls - not exceeding 150mm thickness - built from blockwork or stone with regular course heights, including mortar of approx. 225mm
- On roof pitches of 12.5° and above



PRODUCTS IN THE RANGE

Intermediate trays: Forms main tray run with one tray on each course of blockwork/stonework running the full length of the abutting roof slope.

Stopend starters: Suits all roof pitches - first component to be installed and fitted at the lowest point on a standard abutment. Collects water gathered by the rest of the system and discharges it from the wall through a weep hole.

Corner starter trays: Suits all roof pitches. Same function as stopend starter tray but is used where the abutting roof comes up to, or beyond, the corner of the main building. Designed to return around the corner of the building for complete protection. Corner starter trays are not supplied with factory fitted lead flashings due to the size and weight of lead flashing required. Flashing in this area should be dealt with separately in the traditional way.


Ridge trays: Suits all roof pitches. Used where a right hand and left hand roof slope come together at an apex to straddle the top two intermediate trays.



**Intermediate tray (LH)
Long Lead**



**Stopend starter tray (LH)
Long Lead**



Ridge tray

225MM BLOCK COURSING - 100MM EXTERNAL WALL THICKNESS (BED)

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	Varies	8201	3-5 Working Days	8203	3-5 Working Days	8205	3-5 Working Days
Intermediate tray LH	Varies	8202	3-5 Working Days	8204	3-5 Working Days	8206	3-5 Working Days
Stopend starter RH	450mm	8231	3-5 Working Days	8233	3-5 Working Days	8235	3-5 Working Days
Stopend starter LH	450mm	8232	3-5 Working Days	8234	3-5 Working Days	8236	3-5 Working Days
Corner starter tray RH*	550mm	7241	3-5 Working Days	7243	3-5 Working Days	7245	3-5 Working Days
Corner starter tray LH*	550mm	7242	3-5 Working Days	7244	3-5 Working Days	7246	3-5 Working Days
Ridge tray	450mm	8261	3-5 Working Days	8262	3-5 Working Days	8263	3-5 Working Days

225MM BLOCK COURSING - 125MM EXTERNAL WALL THICKNESS (BED)

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	Varies	8203	3-5 Working Days	8205	3-5 Working Days	8207	3-5 Working Days
Intermediate tray LH	Varies	8204	3-5 Working Days	8206	3-5 Working Days	8208	3-5 Working Days
Stopend starter RH	450mm	8233	3-5 Working Days	8235	3-5 Working Days	8237	3-5 Working Days
Stopend starter LH	450mm	8234	3-5 Working Days	8236	3-5 Working Days	8238	3-5 Working Days
Corner starter tray RH*	550mm	7243	3-5 Working Days	7245	3-5 Working Days	7247	3-5 Working Days
Corner starter tray LH	550mm	7244	3-5 Working Days	7246	3-5 Working Days	7248	3-5 Working Days
Ridge tray	450mm	8262	3-5 Working Days	8263	3-5 Working Days	8264	3-5 Working Days

225MM BLOCK COURSING - 150MM EXTERNAL WALL THICKNESS (BED)

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Intermediate tray RH	Varies	8205	3-5 Working Days	8207	3-5 Working Days	8209	3-5 Working Days
Intermediate tray LH	Varies	8206	3-5 Working Days	8208	3-5 Working Days	8210	3-5 Working Days
Stopend starter RH	450mm	8235	3-5 Working Days	8237	3-5 Working Days	8239	3-5 Working Days
Stopend starter LH	450mm	8236	3-5 Working Days	8238	3-5 Working Days	8240	3-5 Working Days
Corner starter tray RH*	550mm	7245	3-5 Working Days	7247	3-5 Working Days	7249	3-5 Working Days
Corner starter tray LH	550mm	7246	3-5 Working Days	7248	3-5 Working Days	7250	3-5 Working Days
Ridge tray	450mm	8263	3-5 Working Days	8264	3-5 Working Days	8265	3-5 Working Days

When ordering, please state roof pitch and whether long or short leads are required.

N.B *Not supplied with factory fitted lead flashings.

INTER-LOC HORIZONTAL CAVITY TRAYS



USE

- At the abutment of a flat roof with a cavity wall
- At the abutment of a lean-to or mono pitch roof with a cavity wall
- Over concrete ring beams
- Over airbricks, cavity liners, ducts, meter boxes, etc.
- On external walls - not exceeding 102.5mm in thickness - built from standard brick, block or stone
- Clear cavity widths of between 50-125mm



PRODUCTS IN THE RANGE

Horizontal Inter-loc cavity trays: The main cavity tray component sections join together by means of a lapped interlocking joint, to form the main cavity tray run. Water is gathered by the cavity tray and is discharged from the wall through a series of weep holes - one weep hole per Inter-loc tray is required.

Corner Units: Allows the integrity of the main cavity tray run to be maintained when it is necessary to turn a corner on a building. Available in either external or internal format.

Stopends: Fitted at the start and finish of the cavity tray run to seal off the open ends and prevent water running back into the cavity.




Existing build
horizontal tray
IL2/E



New build
horizontal tray
IL4



New build
external corner
EXT90



New build
internal corner
INT90

NEW BUILD APPLICATIONS


DESCRIPTION	EFFECTIVE LENGTH	PRODUCT CODE	LEAD TIME
Inter-loc horizontal tray	4 brick / 900mm	IL4	Next Working Day
Inter-loc horizontal tray	2 brick / 450mm	IL2	Next Working Day
External 90° corner	1 brick / 220mm	EXT90	Next Working Day
Internal 90° corner	1 brick / 220mm	INT90	Next Working Day
External 135° corner	330mm	EXT135	3-5 Working Days
Internal 135° corner	150mm	INT135	3-5 Working Days
Stopend RH	-	SERH	Next Working Day
Stopend LH	-	SELH	Next Working Day

EXISTING APPLICATIONS

DESCRIPTION	EFFECTIVE LENGTH	PRODUCT CODE	LEAD TIME
Inter-loc horizontal tray	2 brick / 450mm	IL2/E	Next Working Day
External 90° corner	1 brick / 220mm	EXT90/E	Next Working Day
Internal 90° corner	1 brick / 220mm	INT90/E	Next Working Day
External 135° corner	330mm	EXT135/E	3-5 Working Days
Internal 135° corner	150mm	INT135/E	3-5 Working Days
Stopend RH	-	SERH	Next Working Day
Stopend LH	-	SELH	Next Working Day

For trays featuring the polystyrene strip mortar barrier insert 'P' at the end of the required product code. This may incur an additional charge.

INTER-LOC HORIZONTAL CAVITY TRAYS **LEADED**



USE

- At the abutment of a flat roof with a cavity wall
- At the abutment of a lean-to or mono pitch roof with a cavity wall
- On external walls - not exceeding 102.5mm in thickness - built from standard brick, block or stone
- Clear cavity widths of between 50-125mm




PRODUCTS IN THE RANGE


Horizontal Inter-loc cavity trays: The main cavity tray component sections join together by means of a lapped interlocking joint, to form the main cavity tray run. Water is gathered by the cavity tray and is discharged from the wall through a series of weep holes - one weep hole per Inter-loc tray is required.

Corner Units: Allows the integrity of the main cavity tray run to be maintained when it is necessary to turn a corner on a building. Available in either external or internal format.


Stopends: Fitted at the start and finish of the cavity tray run to seal off the open ends and prevent water running back into the cavity.




4 brick
300mm drop lead
IL4



2 brick tray
150mm drop lead
IL2



External corner
300mm drop lead
EXT90



Internal corner
150mm drop lead
INT90

NEW BUILD APPLICATIONS - 150MM DROP LEAD

DESCRIPTION	EFFECTIVE LENGTH	PRODUCT CODE	LEAD TIME
Inter-loc horizontal tray	4 brick / 900mm	IL4L150	Next Working Day
Inter-loc horizontal tray	2 brick / 450mm	IL2L150	Next Working Day
External 90° corner	1 brick / 220mm	EXT90L150	Next Working Day
Internal 90° corner	1 brick / 220mm	INT90L150	Next Working Day
External 135° corner	330mm	EXT135L150	3-5 Working Days
Internal 135° corner	150mm	INT135L150	3-5 Working Days
Stopend RH	-	SERH	Next Working Day
Stopend LH	-	SELH	Next Working Day

NEW BUILD APPLICATIONS - 300MM DROP LEAD

DESCRIPTION	EFFECTIVE LENGTH	PRODUCT CODE	LEAD TIME
Inter-loc horizontal tray	4 brick / 900mm	IL4L300	Next Working Day
Inter-loc horizontal tray	2 brick / 450mm	IL2L300	Next Working Day
External 90° corner	1 brick / 220mm	EXT90L300	Next Working Day
Internal 90° corner	1 brick / 220mm	INT90L300	Next Working Day
External 135° corner	330mm	EXT135L300	3-5 Working Days
Internal 135° corner	150mm	INT135L300	3-5 Working Days
Stopend RH	-	SERH	Next Working Day
Stopend LH	-	SELH	Next Working Day

SYSTEM 2000 HORIZONTAL CAVITY TRAYS



USE

- At the abutment of a flat roof with a cavity wall
- At the abutment of a lean-to or mono pitch roof with a cavity wall
- Over concrete ring beams
- Over airbricks, cavity liners, ducts, meter boxes, etc.
- Clear cavity widths of between 50-150mm




PRODUCTS IN THE RANGE


Horizontal cavity trays: The main cavity tray component sections join together by means of a lapped joint, sealed with factory applied butyl masking tape, to form the main cavity tray run. Water is gathered by the cavity tray and is discharged from the wall through a series of weep holes.

Corner Units: Allows the integrity of the main cavity tray run to be maintained when it is necessary to turn a corner on a building. Available in either external or internal format.


Stopends: Fitted at the start and finish of the cavity tray run to seal off the open ends and prevent water running back into the cavity.




Horizontal tray



External corner



Internal corner



Stopend (LH)

SYSTEM 2000 HORIZONTAL - 50-99MM

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:			
		50-74MM	LEAD TIME	75-99MM	LEAD TIME
Horizontal tray	880/830mm	2075/880/50	Next Working Day	2075/880/75	Next Working Day
Horizontal tray	460/410mm	2075/460/50	Next Working Day	2075/460/75	Next Working Day
External 90° corner	-	2010/50	Next Working Day	2010/75	Next Working Day
Internal 90° corner	-	2011/50	Next Working Day	2011/75	Next Working Day
External 135° corner	-	2012/50	3-5 Working Days	2012/75	3-5 Working Days
Internal 135° corner	-	2013/50	3-5 Working Days	2013/75	3-5 Working Days
Stopend RH	-	2003/50	Next Working Day	2003/75	Next Working Day
Stopend LH	-	2004/50	Next Working Day	2004/75	Next Working Day

SYSTEM 2000 HORIZONTAL - 100-150MM

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:			
		100-124MM	LEAD TIME	125-150MM	LEAD TIME
Horizontal tray	880/830mm	2075/880/100	Next Working Day	2075/880/150	Next Working Day
Horizontal tray	460/410mm	2075/460/100	Next Working Day	2075/460/150	Next Working Day
External 90° corner	-	2010/100	Next Working Day	2010/150	Next Working Day
Internal 90° corner	-	2011/100	Next Working Day	2011/150	Next Working Day
External 135° corner	-	2012/100	3-5 Working Days	2012/150	3-5 Working Days
Internal 135° corner	-	2013/100	3-5 Working Days	2013/150	3-5 Working Days
Stopend RH	-	2003/100	Next Working Day	2003/150	Next Working Day
Stopend LH	-	2004/100	Next Working Day	2004/150	Next Working Day

For trays featuring the polystyrene strip mortar barrier insert 'P' at the end of the required product code. This may incur an additional charge.

SYSTEM 2000E HORIZONTAL CAVITY TRAYS

REFURBISHMENT



USE

- For remedial work where a horizontal cavity tray must be inserted into an existing wall
- At the abutment of a flat roof with a cavity wall
- At the abutment of a lean-to or mono pitch roof with a cavity wall
- Over airbricks, cavity liners, ducts, meter boxes, etc.
- On external walls - not exceeding 102.5mm in thickness - built from standard brick, block or stone
- Clear cavity widths of between 50-125mm



PRODUCTS IN THE RANGE

Horizontal cavity trays: The main cavity tray component. Sections join together by means of a lapped joint, sealed with factory applied butyl mastic tape, to form the main cavity tray run. Water is gathered by the cavity tray and is discharged from the wall through a series of weep holes.

Corner Units: Allows the integrity of the main cavity tray run to be maintained when it is necessary to turn a corner on a building. Available in either external or internal format.

Stopends: Fitted at the start and finish of the cavity tray run to seal off the open ends and prevent water running back into the cavity.



E-Horizontal tray



External corner



Internal corner




Stopend (LH)

SYSTEM 2000 HORIZONTAL - 50-125MM

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74MM	LEAD TIME	75-99MM	LEAD TIME	100-125MM	LEAD TIME
Horizontal tray	460/440mm	2005/50	Next Working Day	2005/75	Next Working Day	2005/100	Next Working Day
External 90° corner	-	2006E/50	3-5 Working Days	2006E/75	3-5 Working Days	2006E/100	3-5 Working Days
Internal 90° corner	-	2007E/50	3-5 Working Days	2007E/75	3-5 Working Days	2007E/100	3-5 Working Days
Stopend RH	-	2003/50	Next Working Day	2003/75	Next Working Day	2003/100	Next Working Day
Stopend LH	-	2004/50	Next Working Day	2004/75	Next Working Day	2004/100	Next Working Day

SYSTEM 2000 HORIZONTAL CAVITY TRAYS **LEADED**



USE

- At the abutment of a lean-to, flat or mono pitch roof and cavity wall
- On external walls - not exceeding 102.5mm in thickness - built from standard brickwork, blockwork or stone
- Clear cavity widths of between 50-125mm



PRODUCTS IN THE RANGE


Horizontal cavity trays: The main cavity tray component. Sections join together by means of a lapped joint, sealed with factory applied butyl mastic tape, to form the main cavity tray run. Water is gathered by the cavity tray and is discharged from the wall through a series of weep holes.

Corner Units: Allows the integrity of the main cavity tray run to be maintained when it is necessary to turn a corner on a building. Available in either external or internal format.

Stopends: Fitted at the start and finish of the cavity tray run to seal off the open ends and prevent water running back into the cavity.




Horizontal tray



External corner



Internal corner



Stopend (LH)

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:			
		50-74MM	LEAD TIME	75-99MM	LEAD TIME
Horizontal tray	880/830mm Short lead	2075/880/50/L150	3-5 Working Days	2075/880/75/L150	3-5 Working Days
Horizontal tray	880/830mm Long lead	2075/880/50/L300	3-5 Working Days	2075/880/75/L300	3-5 Working Days
Horizontal tray	460/410mm Short lead	2075/460/50/L150	3-5 Working Days	2075/460/75/L150	3-5 Working Days
Horizontal tray	460/440mm Long lead	2075/460/50/L300	3-5 Working Days	2075/460/75/L300	3-5 Working Days
External 90° corner	Short lead	2010L150/50	3-5 Working Days	2010L150/75	3-5 Working Days
External 90° corner	Long lead	2010L300/50	3-5 Working Days	2010L300/75	3-5 Working Days
Internal 90° corner	Short lead	2011L150/50	3-5 Working Days	2011L150/75	3-5 Working Days
Internal 90° corner	Long lead	2011L300/50	3-5 Working Days	2011L300/75	3-5 Working Days
External 135° corner	Long lead	2012L300/50	3-5 Working Days	2012L300/75	3-5 Working Days
Internal 135° corner	Long lead	2013L300/50	3-5 Working Days	2013L300/75	3-5 Working Days
Stepend RH	-	2003/50	Next Working Day	2003/75	Next Working Day
Stepend LH	-	2004/50	Next Working Day	2004/75	Next Working Day

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:	
		100-125MM	LEAD TIME
Horizontal tray	880/830mm Short lead	2075/880/100/L150	3-5 Working Days
Horizontal tray	880/830mm Long lead	2075/880/100/L300	3-5 Working Days
Horizontal tray	460/410mm Short lead	2075/460/100/L150	3-5 Working Days
Horizontal tray	460/440mm Long lead	2075/460/100/L300	3-5 Working Days
External 90° corner	Short lead	2010L150/100	3-5 Working Days
External 90° corner	Long lead	2010L300/100	3-5 Working Days
Internal 90° corner	Short lead	2011L150/100	3-5 Working Days
Internal 90° corner	Long lead	2011L300/100	3-5 Working Days
External 135° corner	Long lead	2012L300/100	3-5 Working Days
Internal 135° corner	Long lead	2013L300/100	3-5 Working Days
Stepend RH	-	2003/100	Next Working Day
Stepend LH	-	2004/100	Next Working Day

GENERAL PURPOSE TRAYS



USE

- For installation in various applications
- Above floor beams
- Roof abutments
- Meter boxes




PRODUCTS IN THE RANGE


Horizontal cavity trays: The main cavity tray component. Sections can be joined together by means of a sealing tape, such as Timloc's GTAPE01 (available separately) to form the main cavity tray run. Water is gathered by the cavity tray and is discharged from the wall through a series of weep holes.

Corner Units: Allows the integrity of the main cavity tray run to be maintained when it is necessary to turn a corner on a building. Available in either external or internal format.


Stopends: Fitted at the start and finish of the cavity tray run to seal off the open ends and prevent water running back into the cavity.




Horizontal tray



External corner




Internal corner



Stopend

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Horizontal tray	2500mm	5201	3-5 Working Days	5202	3-5 Working Days	5203	3-5 Working Days
External 90° corner	NA	5210	3-5 Working Days	5212	3-5 Working Days	5214	3-5 Working Days
Internal 90° corner	NA	5211	3-5 Working Days	5213	3-5 Working Days	5215	3-5 Working Days
Stopend RH	NA	5220	3-5 Working Days	5222	3-5 Working Days	5224	3-5 Working Days
Stopend LH	NA	5221	3-5 Working Days	5223	3-5 Working Days	5225	3-5 Working Days

HORIZONTAL PARAPET TRAYS



USE


- For installation directly into the internal wall of parapet wall applications




PRODUCTS IN THE RANGE

Horizontal parapet trays: The main cavity tray component. Sections can be joined together by means of a sealing tape, such as Timloc's GTAPE01 (available separately) to form the main cavity tray run. Water is gathered by the cavity tray and is discharged from the wall through a series of weep holes.


Corner Units: Allows the integrity of the main cavity tray run to be maintained when it is necessary to turn a corner on a building. Available in either external or internal format.



Horizontal tray




External corner



Internal corner

DESCRIPTION	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
		50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Horizontal parapet tray	2500mm	5301	3-5 Working Days	5302	3-5 Working Days	5303	3-5 Working Days
External 90° corner	NA	5310	3-5 Working Days	5312	3-5 Working Days	5314	3-5 Working Days
Internal 90° corner	NA	5311	3-5 Working Days	5313	3-5 Working Days	5315	3-5 Working Days

LINTEL TRAYS



USE


- On steel lintels situated in external walls
- On external walls - not exceeding 102.5mm in thickness - built in standard brick, block or stone




PRODUCTS IN THE RANGE

Lintel trays: The main cavity tray component to be built over window and door openings. Allow 150mm overbearing either side, to be trimmed or joined when longer than 2500mm openings. Water is gathered by the cavity tray and is discharged from the wall through a series of weep holes.

Stopends: Fitted at the start and finish of the cavity tray run to seal off the open ends and prevent water running back into the cavity.



Lintel tray




Lintel stopend

DESCRIPTION	RISE	LENGTH	PRODUCT CODES TO SUIT CLEAR CAVITY WIDTHS OF:					
			50-74 MM	LEAD TIME	75-99 MM	LEAD TIME	100-125 MM	LEAD TIME
Lintel tray	100mm	2500mm	5001	3-5 Working Days	5002	3-5 Working Days	5003	3-5 Working Days
Lintel tray	150mm	2500mm	5004	3-5 Working Days	5005	3-5 Working Days	5006	3-5 Working Days
Lintel tray	225mm	2500mm	5007	3-5 Working Days	5008	3-5 Working Days	5009	3-5 Working Days

DESCRIPTION	PRODUCT CODE	LEAD TIME
Lintel stopend	LS01	Next Working Day

THRESHOLD TRAYS



USE

- Preformed DPC threshold protection trays to suit standard openings



PRODUCTS IN THE RANGE


Threshold protection trays: Pre-shaped, waterproof barrier fitted at low-level door openings to stop moisture from entering the building. It channels any water within the cavity safely outward and keeps the junction between inside and outside materials, like flooring, insulation and damp-proof layers protected. By providing reliable damp control at door thresholds, it supports compliance with building regulations for level access installations.



Threshold tray

DESCRIPTION	LENGTH	PRODUCT CODE	LEAD TIME
DPC Threshold protection tray	Various	TPT01	3-5 Working Days

DOOR & WINDOW TRAYS



USE

- Around the opening of an external door or window with an arched top or a circular external window
- On external walls - built from brick, block or stone as well as timber frame constructions - of any thickness and any cavity width




HOW TO ORDER


Arch cavity trays are made to order, so please supply full construction details. Ideally these will include a fully dimensioned drawing showing door/window opening size and wall construction details. If this is not possible the minimum information required is:

- Thickness of outer leaf and cavity width
- Clear opening width and height of door/window opening
- Radius of curvature
- Position of spring line

With this data Timloc will be able to produce and despatch a dimensioned drawing for your approval.




Arched door



Circular window

PURPOSE MADE TRAYS



USE

- Made-to-measure trays for wherever DPC is used to form a horizontal cavity tray
- To substitute the cutting, moulding and sealing of a DPC when forming cavity trays, angles, stop ends etc.




PRODUCTS IN THE RANGE


- Cavity trays for brick support systems
- Parapet cavity tray systems
- Pier, column and corner cloaks
- Threshold trays
- Change of level units
- Radius units
- Stop end and junction cappings
- Ring beam cavity tray systems

HOW TO ORDER

These products are made to order, so please supply full construction details, ideally including fully dimensioned drawings.



**Door closer cloak
(RH/LH)**



**Threshold
tray**

PRODUCT CODES

For the entire Timloc range of cavity trays.

Product Code	Description	Lead Time	Page
10001	Everdry 225mm Intermediate Brickwork Cavity Tray Right Hand	Next Working Day	6
10002	Everdry 225mm Intermediate Brickwork Cavity Tray Left Hand	Next Working Day	6
10011	Everdry 420mm Intermediate Brickwork Cavity Tray Right Hand	Next Working Day	6
10012	Everdry 420mm Intermediate Brickwork Cavity Tray Left Hand	Next Working Day	6
10031	Everdry 225mm Stop End Starter Brickwork Cavity Tray RH & LH	Next Working Day	6
10041	Everdry 225mm Corner Starter Brickwork Cavity Tray RH & LH	Next Working Day	6
10061	Everdry 225mm Ridge Brickwork Cavity Tray	Next Working Day	6
10062	Everdry 420mm Ridge Brickwork Cavity Tray	Next Working Day	6
10001P	Poly Strip Everdry 225mm Intermediate Brickwork Cavity Tray Right Hand	Next Working Day	6
10002P	Poly Strip Everdry 225mm Intermediate Brickwork Cavity Tray Left Hand	Next Working Day	6
10011P	Poly Strip Everdry 420mm Intermediate Brickwork Cavity Tray Right Hand	Next Working Day	6
10012P	Poly Strip Everdry 420mm Intermediate Brickwork Cavity Tray Left Hand	Next Working Day	6
10031P	Poly Strip Everdry 225mm Stop End Starter Brickwork Cavity Tray RH & LH	Next Working Day	6
10041P	Poly Strip Everdry 225mm Corner Starter Brickwork Cavity Tray RH & LH	Next Working Day	6
10061P	Poly Strip Everdry 225mm Ridge Brickwork Cavity Tray	Next Working Day	6
10062P	Poly Strip Everdry 420mm Ridge Brickwork Cavity Tray	3-5 Working Days	6
7101-7102	Everdry 450mm Intermediate Stonework Cavity Tray	Next Working Day	8
7103-7104	Everdry 450mm Intermediate Stonework Cavity Tray	3-5 Working Days	8
7105-7106	Everdry 450mm Intermediate Stonework Cavity Tray	3-5 Working Days	8
7107-7110	Everdry 450mm Intermediate Stonework Cavity Tray	3-5 Working Days	8
7111-7120	Everdry 625mm Intermediate Stonework Cavity Tray	3-5 Working Days	8
7121-7130	Everdry 1250mm Intermediate Stonework Cavity Tray	3-5 Working Days	8
7131	Everdry 450mm Stop End Starter Stonework Cavity Tray RH & LH	Next Working Day	8
7132-7139	Everdry 450mm Stop End Starter Stonework Cavity Tray RH & LH	3-5 Working Days	8
7141 - 7142	Everdry 550mm Corner Starter Stonework Cavity Tray RH & LH	Next Working Day	8
7143-7150	Everdry 550mm Corner Starter Stonework Cavity Tray RH & LH	3-5 Working Days	8
7161	Everdry 450mm Ridge Stonework Cavity Tray	Next Working Day	8
7162-7165	Everdry 450mm Ridge Stonework Cavity Tray	3-5 Working Days	8
7101P-7102P	Poly Strip Everdry 450mm Intermediate Stonework Cavity Tray	Next Working Day	8
7103P-7110P	Poly Strip Everdry 450mm Intermediate Stonework Cavity Tray	3-5 Working Days	8
7111P-7120P	Poly Strip Everdry 625mm Intermediate Stonework Cavity Tray	3-5 Working Days	8
7121P-7130P	Poly Strip Everdry 1250mm Intermediate Stonework Cavity Tray	3-5 Working Days	8
7131P	Poly Strip Everdry 450mm Stop End Starter Stonework Cavity Tray RH & LH	Next Working Day	8
7132P-7139P	Poly Strip Everdry 450mm Stop End Starter Stonework Cavity Tray RH & LH	3-5 Working Days	8
7141P-7142P	Poly Strip Everdry 550mm Corner Starter Stonework Cavity Tray RH & LH	Next Working Day	8
7143P-7150P	Poly Strip Everdry 550mm Corner Starter Stonework Cavity Tray RH & LH	3-5 Working Days	8
7161P	Poly Strip Everdry 450mm Ridge Stonework Cavity Tray	Next Working Day	8
7162P-7165P	Poly Strip Everdry 450mm Ridge Stonework Cavity Tray	3-5 Working Days	8
7201-7202	Everdry 625mm Intermediate Blockwork Cavity Tray	Next Working Day	10
7203-7210	Everdry 625mm Intermediate Blockwork Cavity Tray	3-5 Working Days	10
7211-7220	Everdry 1250mm Intermediate Blockwork Cavity Tray	3-5 Working Days	10
7231	Everdry 450mm Stop End Starter Blockwork Cavity Tray RH & LH	Next Working Day	10
7232-7239	Everdry 450mm Stop End Starter Blockwork Cavity Tray RH & LH	3-5 Working Days	10
7241-7250	Everdry 550mm Corner Starter Blockwork Cavity Tray RH & LH	3-5 Working Days	10
7261	Everdry 625mm Ridge Blockwork Cavity Tray	Next Working Day	10
7262-7265	Everdry 625mm Ridge Blockwork Cavity Tray	3-5 Working Days	10
7201P-7202P	Poly Strip Everdry 625mm Intermediate Blockwork Cavity Tray	Next Working Day	10

Product Code	Description	Lead Time	Page
7203P-7210P	Poly Strip Everdry 625mm Intermediate Blockwork Cavity Tray	3-5 Working Days	10
7211P-7220P	Poly Strip Everdry 1250mm Intermediate Blockwork Cavity Tray	3-5 Working Days	10
7231P	Poly Strip Everdry 450mm Stop End Starter Blockwork Cavity Tray RH & LH	Next Working Day	10
7232P-7239P	Poly Strip Everdry 450mm Stop End Starter Blockwork Cavity Tray RH & LH	3-5 Working Days	10
7241P-7250P	Poly Strip Everdry 550mm Corner Starter Blockwork Cavity Tray RH & LH	3-5 Working Days	10
7261P	Poly Strip Everdry 625mm Ridge Blockwork Cavity Tray	Next Working Day	10
7262P-7265P	Poly Strip Everdry 625mm Ridge Blockwork Cavity Tray	3-5 Working Days	10
20001	Everdry Intermediate Brickwork Leaded Cavity Tray Right Hand	3-5 Working Days for 10° - 22.5°. Next Working Day available on 25° and above only.	12
20002	Everdry Intermediate Brickwork Leaded Cavity Tray Left Hand		12
20031/32	Everdry 225mm Stop End Starter Brickwork Leaded Cavity Tray RH & LH		12
20041/42	Everdry 225mm Corner Starter Brickwork Leaded Cavity Tray RH & LH		12
20061	Everdry 225mm Ridge Brickwork Leaded Cavity Tray		12
20062	Everdry 420mm Ridge Brickwork Leaded Cavity Tray		12
8101-8110	Everdry Intermediate Stonework Leaded Cavity Tray	3-5 Working Days	14
8131-8140	Everdry 450mm Stop End Starter Stonework Leaded Cavity Tray RH & LH	Next Working Day	14
7241-7250	Everdry 550mm Corner Starter Stonework Leaded Cavity Tray RH & LH	3-5 Working Days	14
8161-8165	Everdry 450mm Ridge Stonework Leaded Cavity Tray RH & LH	3-5 Working Days	14
8201-8210	Everdry Intermediate Blockwork Leaded Cavity Tray	3-5 Working Days	16
8231-8240	Everdry 450mm Stop End Starter Blockwork Leaded Cavity Tray RH & LH	3-5 Working Days	16
7241-7250	Everdry 550mm Corner Starter Blockwork Leaded Cavity Tray RH & LH	3-5 Working Days	16
8261-8265	Everdry 450mm Ridge Blockwork Leaded Cavity Tray RH & LH	3-5 Working Days	16
IL2	Inter-loc Horizontal Cavity Tray New Build 2 Brick 50-125mm Cavity	Next Working Day	18
IL4	Inter-loc Horizontal Cavity Tray New Build 4 Brick 50-125mm Cavity	Next Working Day	18
EXT90	Inter-loc Horizontal 90° External Corner Cavity Tray New Build	Next Working Day	18
INT90	Inter-loc Horizontal 90° Internal Corner Cavity Tray New Build	Next Working Day	18
EXT135	Inter-loc Horizontal 135° External Corner Cavity Tray New Build	3-5 Working Days	18
INT135	Inter-loc Horizontal 135° Internal Corner Cavity Tray New Build	3-5 Working Days	18
SERH	Inter-loc Horizontal Cavity Tray Right Hand Stop End New Build & Refurb	Next Working Day	18
SELH	Inter-loc Horizontal Cavity Tray Left Hand Stop End New Build & Refurb	Next Working Day	18
IL2/E	Inter-loc Horizontal Cavity Tray Refurb 2 Brick 50-125mm Cavity	Next Working Day	18
EXT90/E	Inter-loc Horizontal 90° External Corner Cavity Tray Refurb	Next Working Day	18
INT90/E	Inter-loc Horizontal 90° Int Corner Cavity Tray Refurb	Next Working Day	18
IL2P	Poly Strip Inter-loc Horizontal Cavity Tray New Build 2 Brick 50-125mm	Next Working Day	18
IL4P	Poly Strip Inter-loc Horizontal Cavity Tray New Build 4 Brick 50-125mm	Next Working Day	18
EXT90P	Poly Strip Inter-loc Horizontal 90° External Corner Cavity Tray New Build	Next Working Day	18
INT90P	Poly Strip Inter-loc Horizontal 90° Internal Corner Cavity Tray New Build	Next Working Day	18
IL2L150	Inter-loc Horizontal Short Leaded Cavity Tray New Build 2 Brick 150mm Drop	Next Working Day	20
IL4L150	Inter-loc Horizontal Short Leaded Cavity Tray New Build 4 Brick 150mm Drop	Next Working Day	20
EXT90L150	Inter-loc Horizontal Short 90° External Corner Leaded Cavity Tray New Build	Next Working Day	20
INT90L150	Inter-loc Horizontal Short 90° Internal Corner Leaded Cavity Tray New Build	Next Working Day	20
EXT135L150	Inter-loc Horizontal Short 135° External Corner Leaded Cavity Tray New Build	3-5 Working Days	20
INT135L150	Inter-loc Horizontal Short 135° Internal Corner Leaded Cavity Tray New Build	3-5 Working Days	20
IL2L300	Inter-loc Horizontal Long Leaded Cavity Tray New Build 2 Brick 300mm Drop	Next Working Day	20
IL4L300	Inter-loc Horizontal Long Leaded Cavity Tray New Build 4 Brick 300mm Drop	Next Working Day	20
EXT90L300	Inter-loc Horizontal Long 90° External Corner Leaded Cavity Tray New Build	Next Working Day	20
INT90L300	Inter-loc Horizontal Long 90° Internal Corner Leaded Cavity Tray New Build	Next Working Day	20
EXT135L300	Inter-loc Horizontal Long 135° External Corner Leaded Cavity Tray New Build	3-5 Working Days	20
INT135L300	Inter-loc Horizontal Long 135° Internal Corner Leaded Cavity Tray New Build	3-5 Working Days	20

Product Code	Description	Lead Time	Page
2075/460/50	System 2000 Horizontal Cavity Tray New Build 460mm 50-74mm	Next Working Day	22
2075/460/75	System 2000 Horizontal Cavity Tray New Build 460mm 75-99mm	Next Working Day	22
2075/460/100	System 2000 Horizontal Cavity Tray New Build 460mm 100-124mm	Next Working Day	22
2075/460/150	System 2000 Horizontal Cavity Tray New Build 460mm 125-150mm	Next Working Day	22
2075/880/50	System 2000 Horizontal Cavity Tray New Build 880mm 50-74mm	Next Working Day	22
2075/880/75	System 2000 Horizontal Cavity Tray New Build 880mm 75-99mm	Next Working Day	22
2075/880/100	System 2000 Horizontal Cavity Tray New Build 880mm 100-124mm	Next Working Day	22
2075/880/150	System 2000 Horizontal Cavity Tray New Build 880mm 125-150mm	Next Working Day	22
2010/50	System 2000 Horizontal External 90° Corner Cavity Tray 50-99mm	Next Working Day	22
2010/75	System 2000 Horizontal External 90° Corner Cavity Tray 75-99mm	Next Working Day	22
2010/100	System 2000 Horizontal External 90° Corner Cavity Tray 100-124mm	Next Working Day	22
2010/150	System 2000 Horizontal External 90° Corner Cavity Tray 125-150mm	Next Working Day	22
2011/50	System 2000 Horizontal Internal 90° Corner Cavity Tray 50-74mm	Next Working Day	22
2011/75	System 2000 Horizontal Internal 90° Corner Cavity Tray 74-99mm	Next Working Day	22
2011/100	System 2000 Horizontal Internal 90° Corner Cavity Tray 100-124mm	Next Working Day	22
2011/150	System 2000 Horizontal Internal 90° Corner Cavity Tray 125-150mm	Next Working Day	22
2012/50	System 2000 Horizontal External 135° Corner Cavity Tray 50-74mm	3-5 Working Days	22
2012/75	System 2000 Horizontal External 135° Corner Cavity Tray 75-99mm	3-5 Working Days	22
2012/100	System 2000 Horizontal External 135° Corner Cavity Tray 100-124mm	3-5 Working Days	22
2012/150	System 2000 Horizontal External 135° Corner Cavity Tray 125-150mm	3-5 Working Days	22
2013/50	System 2000 Horizontal Internal 135° Corner Cavity Tray 50-74mm	3-5 Working Days	22
2013/75	System 2000 Horizontal Internal 135° Corner Cavity Tray 75-99mm	3-5 Working Days	22
2013/100	System 2000 Horizontal Internal 135° Corner Cavity Tray 100-124mm	3-5 Working Days	22
2013/150	System 2000 Horizontal Internal 135° Corner Cavity Tray 125-150mm	3-5 Working Days	22
2003/50	System 2000 Horizontal Cavity Tray Stop End Right Hand 50mm	Next Working Day	22
2003/75	System 2000 Horizontal Cavity Tray Stop End Right Hand 75mm	Next Working Day	22
2003/100	System 2000 Horizontal Cavity Tray Stop End Right Hand 100mm	Next Working Day	22
2003/150	System 2000 Horizontal Cavity Tray Stop End Right Hand 150mm	Next Working Day	22
2004/50	System 2000 Horizontal Cavity Tray Stop End Left Hand 50mm	Next Working Day	22
2004/75	System 2000 Horizontal Cavity Tray Stop End Left Hand 75mm	Next Working Day	22
2004/100	System 2000 Horizontal Cavity Tray Stop End Left Hand 100mm	Next Working Day	22
2004/150	System 2000 Horizontal Cavity Tray Stop End Left Hand 150mm	Next Working Day	22
2075/460P50	Poly Strip System 2000 Horizontal Cavity Tray New Build 460mm 50-74mm	Next Working Day	22
2075/460P75	Poly Strip System 2000 Horizontal Cavity Tray New Build 460mm 75-99mm	Next Working Day	22
2075/460P100	Poly Strip System 2000 Horizontal Cavity Tray New Build 460mm 100-124mm	Next Working Day	22
2075/460P150	Poly Strip System 2000 Horizontal Cavity Tray New Build 460mm 125-150mm	Next Working Day	22
2075/880P50	Poly Strip System 2000 Horizontal Cavity Tray New Build 880mm 50-74mm	Next Working Day	22
2075/880P75	Poly Strip System 2000 Horizontal Cavity Tray New Build 880mm 75-99mm	Next Working Day	22
2075/880P100	Poly Strip System 2000 Horizontal Cavity Tray New Build 880mm 100-124mm	Next Working Day	22
2075/880P150	Poly Strip System 2000 Horizontal Cavity Tray New Build 880mm 125-150mm	Next Working Day	22
2010P/50	Poly Strip System 2000 Horizontal External 90° Corner Cavity Tray 50-99mm	Next Working Day	22
2010P/75	Poly Strip System 2000 Horizontal External 90° Corner Cavity Tray 75-99mm	Next Working Day	22
2010P/100	Poly Strip System 2000 Horizontal External 90° Corner Cavity Tray 100-124mm	Next Working Day	22
2010P/150	Poly Strip System 2000 Horizontal External 90° Corner Cavity Tray 125-150mm	Next Working Day	22
2011P/50	Poly Strip System 2000 Horizontal Internal 90° Corner Cavity Tray 50-74mm	Next Working Day	22
2011P/75	Poly Strip System 2000 Horizontal Internal 90° Corner Cavity Tray 74-99mm	Next Working Day	22
2011P/100	Poly Strip System 2000 Horizontal Internal 90° Corner Cavity Tray 100-124mm	Next Working Day	22
2011P/150	Poly Strip System 2000 Horizontal Internal 90° Corner Cavity Tray 125-150mm	Next Working Day	22
2012P/50	Poly Strip System 2000 Horizontal External 135° Corner Cavity Tray 50-74mm	3-5 Working Days	22
2012P/75	Poly Strip System 2000 Horizontal External 135° Corner Cavity Tray 75-99mm	3-5 Working Days	22
2012P/100	Poly Strip System 2000 Horizontal External 135° Corner Cavity Tray 100-124mm	3-5 Working Days	22
2012P/150	Poly Strip System 2000 Horizontal External 135° Corner Cavity Tray 125-150mm	3-5 Working Days	22

Product Code	Description	Lead Time	Page
2013P/50	Poly Strip System 2000 Horizontal Internal 135° Corner Cavity Tray 50-74mm	3-5 Working Days	22
2013P/75	Poly Strip System 2000 Horizontal Internal 135° Corner Cavity Tray 75-99mm	3-5 Working Days	22
2013P/100	Poly Strip System 2000 Horizontal Internal 135° Corner Cavity Tray 100-124mm	3-5 Working Days	22
2013P/150	Poly Strip System 2000 Horizontal Internal 135° Corner Cavity Tray 125-150mm	3-5 Working Days	22
2005/50	System 2000E Horizontal Cavity Tray Refurbishment 460mm 50-74mm	Next Working Day	24
2005/75	System 2000E Horizontal Cavity Tray Refurbishment 460mm 75-99mm	Next Working Day	24
2005/100	System 2000E Horizontal Cavity Tray Refurbishment 460mm 100-125mm	Next Working Day	24
2006E/50	System 2000E Horizontal Ext 90° Corner Cavity Tray Refurbishment 50-74mm	3-5 Working Days	24
2006E/75	System 2000E Horizontal Unlead Ext 90° Corner Cavity Tray Refurb 75-99mm	3-5 Working Days	24
2006E/100	System 2000E Horizontal Unlead Ext 90° Corner Cavity Tray Refurb 100-125mm	3-5 Working Days	24
2007E/50	System 2000E Horizontal Unlead Int 90° Corner Cavity Tray Refurb 50-74mm	3-5 Working Days	24
2007E/75	System 2000E Horizontal Unlead Int 90° Corner Cavity Tray Refurb 74-99mm	3-5 Working Days	24
2007E/100	System 2000E Horizontal Unlead Int 90° Corner Cavity Tray Refurb 100-125mm	3-5 Working Days	24
2075/460/50/L150	System 2000 Horizontal Short Ledged Cavity Tray New Build 460mm 50-74mm	3-5 Working Days	26
2075/460/75/L150	System 2000 Horizontal Short Ledged Cavity Tray New Build 460mm 75-99mm	3-5 Working Days	26
2075/460/100/L150	System 2000 Horizontal Short Ledged Cavity Tray New Build 460mm 100-125mm	3-5 Working Days	26
2075/460/50/L300	System 2000 Horizontal Long Ledged Cavity Tray New Build 460mm 50-74mm	3-5 Working Days	26
2075/460/75/L300	System 2000 Horizontal Long Ledged Cavity Tray New Build 460mm 75-99mm	3-5 Working Days	26
2075/460/100/L300	System 2000 Horizontal Long Ledged Cavity Tray New Build 460mm 100-125mm	3-5 Working Days	26
2075/880/50/L150	System 2000 Horizontal Short Ledged Cavity Tray New Build 880mm 50-74mm	3-5 Working Days	26
2075/880/75/L150	System 2000 Horizontal Short Ledged Cavity Tray New Build 880mm 75-99mm	3-5 Working Days	26
2075/880/100/L150	System 2000 Horizontal Short Ledged Cavity Tray New Build 880mm 100-125mm	3-5 Working Days	26
2075/880/50/L300	System 2000 Horizontal Long Ledged Cavity Tray New Build 880mm 50-74mm	3-5 Working Days	26
2075/880/75/L300	System 2000 Horizontal Long Ledged Cavity Tray New Build 880mm 75-99mm	3-5 Working Days	26
2075/880/100/L300	System 2000 Horizontal Long Ledged Cavity Tray New Build 880mm 100-125mm	3-5 Working Days	26
2010L150/50	System 2000 Horizontal External 90° Corner Ledged Cavity Tray 50-74mm	3-5 Working Days	26
2010L150/75	System 2000 Horizontal External 90° Corner Ledged Cavity Tray 75-99mm	3-5 Working Days	26
2010L150/100	System 2000 Horizontal External 90° Corner Ledged Cavity Tray 100-125mm	3-5 Working Days	26
2010L300/50	System 2000 Horizontal External 90° Corner Ledged Cavity Tray 50-74mm	3-5 Working Days	26
2010L300/75	System 2000 Horizontal External 90° Corner Ledged Cavity Tray 75-99mm	3-5 Working Days	26
2010L300/100	System 2000 Horizontal External 90° Corner Ledged Cavity Tray 100-125mm	3-5 Working Days	26
2011L150/50	System 2000 Horizontal Internal 90° Corner Ledged Cavity Tray 50-74mm	3-5 Working Days	26
2011L150/75	System 2000 Horizontal Internal 90° Corner Ledged Cavity Tray 75-99mm	3-5 Working Days	26
2011L150/100	System 2000 Horizontal Internal 90° Corner Ledged Cavity Tray 100-125mm	3-5 Working Days	26
2011L300/50	System 2000 Horizontal Internal 90° Corner Ledged Cavity Tray 50-74mm	3-5 Working Days	26
2011L300/75	System 2000 Horizontal Internal 90° Corner Ledged Cavity Tray 75-99mm	3-5 Working Days	26
2011L300/100	System 2000 Horizontal Internal 90° Corner Ledged Cavity Tray 100-125mm	3-5 Working Days	26
2012L300/50	System 2000 Horizontal External 135° Corner Ledged Cavity Tray 50-74mm	3-5 Working Days	26
2012L300/75	System 2000 Horizontal External 135° Corner Ledged Cavity Tray 75-99mm	3-5 Working Days	26
2012L300/100	System 2000 Horizontal External 135° Corner Ledged Cavity Tray 100-125mm	3-5 Working Days	26
2013L300/50	System 2000 Horizontal Internal 135° Corner Ledged Cavity Tray 50-74mm	3-5 Working Days	26
2013L300/75	System 2000 Horizontal Internal 135° Corner Ledged Cavity Tray 75-99mm	3-5 Working Days	26
2013L300/100	System 2000 Horizontal Internal 135° Corner Ledged Cavity Tray 100-125mm	3-5 Working Days	26
5201	General Purpose Horizontal Cavity Tray 50-74mm	3-5 Working Days	28
5202	General Purpose Horizontal Cavity Tray 75-99mm	3-5 Working Days	28
5203	General Purpose Horizontal Cavity Tray 100-125mm	3-5 Working Days	28
5210	General Purpose External 90° Corner Cavity Tray 50-74mm	3-5 Working Days	28
5212	General Purpose External 90° Corner Cavity Tray 75-99mm	3-5 Working Days	28
5214	General Purpose External 90° Corner Cavity Tray 100-125mm	3-5 Working Days	28

Product Code	Description	Lead Time	Page
5211	General Purpose Internal 90° Corner Cavity Tray 50-74mm	3-5 Working Days	28
5213	General Purpose Internal 90° Corner Cavity Tray 75-99mm	3-5 Working Days	28
5215	General Purpose Internal 90° Corner Cavity Tray 100-125mm	3-5 Working Days	28
5520	General Purpose Stopend Cavity Tray RH 50-74mm	3-5 Working Days	28
5222	General Purpose Stopend Cavity Tray RH 75-99mm	3-5 Working Days	28
5224	General Purpose Stopend Cavity Tray RH 100-125mm	3-5 Working Days	28
5221	General Purpose Stopend Cavity Tray LH 50-74mm	3-5 Working Days	28
5223	General Purpose Stopend Cavity Tray LH 75-99mm	3-5 Working Days	28
5225	General Purpose Stopend Cavity Tray LH 100-125mm	3-5 Working Days	28
5301	Horizontal Parapet Horizontal Cavity Tray 50-74mm	3-5 Working Days	29
5302	Horizontal Parapet Horizontal Cavity Tray 75-99mm	3-5 Working Days	29
5303	Horizontal Parapet Horizontal Cavity Tray 100-125mm	3-5 Working Days	29
5310	Horizontal Parapet External 90° Corner Cavity Tray 50-74mm	3-5 Working Days	29
5312	Horizontal Parapet External 90° Corner Cavity Tray 75-99mm	3-5 Working Days	29
5314	Horizontal Parapet External 90° Corner Cavity Tray 100-125mm	3-5 Working Days	29
5311	Horizontal Parapet Internal 90° Corner Cavity Tray 50-74mm	3-5 Working Days	29
5313	Horizontal Parapet Internal 90° Corner Cavity Tray 75-99mm	3-5 Working Days	29
5315	Horizontal Parapet Internal 90° Corner Cavity Tray 100-125mm	3-5 Working Days	29
5001	Lintel Cavity Tray 100mm Rise 50-74mm	3-5 Working Days	30
5002	Lintel Cavity Tray 100mm Rise 75-99mm	3-5 Working Days	30
5003	Lintel Cavity Tray 100mm Rise 100-125mm	3-5 Working Days	30
5004	Lintel Cavity Tray 150mm Rise 50-74mm	3-5 Working Days	30
5005	Lintel Cavity Tray 150mm Rise 75-99mm	3-5 Working Days	30
5006	Lintel Cavity Tray 150mm Rise 100-125mm	3-5 Working Days	30
5007	Lintel Cavity Tray 225mm Rise 50-74mm	3-5 Working Days	30
5008	Lintel Cavity Tray 225mm Rise 75-99mm	3-5 Working Days	30
5009	Lintel Cavity Tray 225mm Rise 100-125mm	3-5 Working Days	30
LS01	Lintel Stopend Cavity Tray	Next Working Day	30
TPT01	Threshold Cavity Tray	3-5 Working Days	31

GUIDES


Whether you need comprehensive product information or condensed data on a specific category, we will have the guide to suit.

Scan the QR code for digital versions of the Timloc product guide, handbook, category guides and datasheets.

For print copies, please email: sales@timloc.co.uk



Compact **A5** guides packed with key information, codes and pack quantities.



Sustainability Guide explains the steps we've taken towards sustainability.

Product Guide features detailed information, codes and pack quantities.



CAVITY TRAYS

Sales | T: 01405 765 567 E: sales@timloc.co.uk Technical | T: 01405 782 769 E: technical@timloc.co.uk

Timloc Building Products | Timloc House, Ozone Park, Howden, East Yorkshire DN14 7SD