


ROOFLINE

by **timloc**

CORBEL VENT

INSTALLATION ADVICE

**Designed for use with corbelled
brickwork details**



-  Satisfies all NHBC requirements
-  Manufactured to BS EN ISO 9001 and BS EN ISO 14001
-  Complies with all relevant Building Regulations
-  Meets all relevant British Standards

1.

Use to ventilate pitched roofs, where the pitch of the roof is 15 degrees or more, and the roof void is attic or loft space.

2.

Do not use to ventilate pitched roofs where the pitch of the roof is less than 15 degrees, flat roofs or any roof where living accommodation is contained within the roof space.

3.

Make sure each ventilator is fixed securely to the top row of corbelling using all eight clips provided.

4.

It is advisable to provide a felt support above the corbel vent. This should project at least 15mm beyond the front of the vent to prevent felt from sagging between the rafters and to maintain a clear air path to the vent front.

5.

Ventilation must be provided for the full length of the eaves and along both sides of the building to create a cross flow ventilation action.

Scan or click to view the
product datasheet

