




by **timloc**

SOFFIT VENT STRIP

INSTALLATION ADVICE

Efficient, strip type eaves ventilator



-  Satisfies all NHBC requirements
-  Manufactured to BS EN ISO 9001 and BS EN ISO 14001
-  Complies with all relevant Building Regulations
-  Meets all relevant British Standards

1.

Use product 1137 to ventilate pitched roofs, where the pitch of the roof is 15 degrees or more, and the roof void is attic or loft space.

2.

Use product 1138 to ventilate pitched roofs, where the pitch of the roof is less than 15 degrees, flat roofs or any roof where living accommodation is contained within the roof space.

3.

Ideally the soffit board should be 6mm in thickness. Thicker boards up to 9mm can be accommodated with care, but it may be necessary to chamfer the edge of the board to make installation easier.

4.

Ensure the ventilator is fixed securely to the back of the fascia board using all the fixing holes provided. Screws are preferable, but nails may be used with care.

5.

Ventilation must be provided for the full length of the eaves and along both sides of the building to create a cross flow ventilation action.

Scan or click to view the
product datasheet

